

# INSTALLATION INSTRUCTIONS

FOR ITEM 106511 Pinecone Mission Pendant

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 36" CHAIN
3. LIGHT CLUSTER
4. SHADE

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Collar from Canopy Loop to release Crossbar.
3. Affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 10lbs and that Electrical Supply Wires remain accessible.
4. Remove Diamond loop from top of Light Cluster.
5. Feed Lead Wires through Shade and then through Diamond Loop. Screw Diamond Loop onto Threaded Nipple to secure Light Cluster inside Shade.
6. Attach desired length of Chain to Diamond Loop on Shade.
7. Weave Lead Wires through every 3rd Link of Chain.
8. Slide Collar and then Canopy over Wires and Chain and allow them to rest on top of Shade.
9. Hang Fixture by connecting loose end of Chain to Canopy Loop.
10. Feed Lead Wires through Canopy Loop and, Following All Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
11. Slide Canopy up to ceiling and secure by screwing Collar onto Canopy Loop.
12. Install 4-E26 60Watt Bulbs(not included) into Sockets.
13. Power on and ENJOY!!!

