

# INSTALLATION INSTRUCTIONS

FOR ITEM 124171 TALL PINES 5 LT VANITY LIGHT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. VANITY LIGHT HARDWARE w/ MOUNTING PLATE
2. GLASS SHADES (QTY 5)
3. CORK WASHER (QTY 5)
4. UNO RING (QTY 5)

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Acorn Nuts from Vanity Hardware to release Mounting Plate. Reserve Acorn Nuts for later use.
3. Using Customer Supplied Hardware, affix Mounting Plate to wall ensuring that connection is suitable to hold a minimum of 20lbs and that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
5. Place Vanity Hardware over Mounting Plate allowing Studs to pass through Back Plate. Secure with reserved Acorn Nuts.
6. Slide Glass Shades over Sockets. Thumb Screws may need to be loosened to allow Shade to fully engage holder. Secure by first tightening Thumb Screws and then placing Cork Washer on Socket and screwing Uno Ring onto Socket Threads until tight.
7. Install 5 Medium Base 60Watt Bulbs(not included) into Sockets.
8. Power on and ENJOY!!!

