

# INSTALLATION INSTRUCTIONS

FOR ITEM 144967 NEVADA WALL SCONCE

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. STAINED GLASS SHADE
2. BACKPLATE

### **Caution:**

**Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screws from Backplate to separate Crossbar. Reserve Screws for later use.
3. Attach Crossbar to Junction Box using Customer Supplied Fasteners ensuring connection is suitable to hold a minimum of 5lbs and that Electrical Supply Wires remain accessible.
4. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
5. Secure Backplate to Junction Box using reserved Screws.
6. Install 2-E12 60Watt Bulbs(not included) into Sockets.
7. Slide Shade Support Bar behind tabs at top of Backplate.
8. Power on and ENJOY!!!

