

# INSTALLATION INSTRUCTIONS

FOR ITEM 145706 Wilderness LED Backlit Window Box

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. WINDOW BOX FRAME
2. STAINED GLASS WINDOW

### **Caution:**

**Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.**

**Be sure power is off at the main breaker box prior to installation.**

**Read all instructions in their entirety before beginning installation.**

**LIGHT BOX FRAME IS DESIGNED TO BE MOUNTED FLUSH TO WALL.  
MODIFICATIONS WILL BE NECESSARY TO RECESS INTO WALL.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Using provided Hanger Bolts (qty 4), affix Window Box Frame to wall ensuring connection is suitable to hold 60lbs.
3. Remove Screws from face of Window Box Frame to release Face Plate.
4. Set Stained Glass Window into Frame and secure with Face Plate and Screws.
5. Plug Power Cord into Wall Outlet.
6. Power on and ENJOY!!!

