

INSTALLATION INSTRUCTIONS

FOR ITEM 178428 Tall Pines 3 LT Vanity Light

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. VANITY HARDWARE
2. GLASS SHADE (QTY 3)

Caution:

**Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Vanity Hardware to release Universal Crossbar. Reserve Balls for later use.
3. Attach Crossbar to J-Box using Customer Supplied Hardware ensuring that connection is suitable to hold a minimum of 10lbs and that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
5. Slide Vanity Hardware onto Crossbar Studs and secure with reserved Brass Balls.
6. Loosen Set Screws on Shade Caps and slide Shades over Sockets. Secure by tightening Set Screws.
7. Install 3-E26 Base 60Watt Bulbs(not included) into Sockets.
8. Power on and ENJOY!!!

