

INSTALLATION INSTRUCTIONS

For Item 181722 Tiffany Candice Wall Sconce

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. WALL SCONCE HARDWARE
2. STAINED GLASS SHADE

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Acorn Nuts from Sconce Backplate to release Crossbar. Reserve Balls for later use.
3. Using Customer Supplied Fasteners, attach Crossbar to Junction Box ensuring that is suitable to hold 5lbs and that Supply Wires remain accessible.
4. Following All Local Codes and Procedures make connection from Lead Wires to Supply Wires.
5. Slide Wall Sconce Hardware onto Crossbar Studs then secure with reserved Acorn Nuts.
6. Slide Shade into Hardware Fitter and secure by threading Uno Ring onto Socket.
7. Install 1-E26 Base 60Watt Bulb(not included) into Socket.
8. Power on and ENJOY!!!

