

INSTALLATION INSTRUCTIONS

FOR ITEM 187291

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY W/ LAMPING CLUSTER
2. SHADE ASSEMBLY

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Remove Brass Balls from Canopy to release Crossbar with Studs. Keep Balls for later use.
3. Using Customer supplied Fasteners, Affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 15 lbs and that Electrical Supply Wires remain accessible.
4. Following all local codes and procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
5. Lift Canopy with Light Cluster up to ceiling allowing crossbar studs to pass through. Secure canopy with Brass Balls from prior.
6. Remove Ball Finial and Washer along with hex nut on bottom of Light Cluster. (These will be used to secure the shade)
7. Install 2x 60W E26 A19 Bulbs (not included) into Sockets.
8. Lift Shade up and secure to Lamping Assembly with the washer along with hex nut on the inside and the Ball Finial on the outside.
9. Power on and ENJOY!!!

