

# INSTALLATION INSTRUCTIONS

FOR ITEM 260940 Sonoma Semi-Flushmount

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. HARDWARE- CANOPY, ARMS, & LIGHT CLUSTER
2. STAINED GLASS SHADE

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy to release Universal Crossbar with Studs. Reserve Balls for later use.
3. Affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 15lbs and that Electrical Supply Wires remain accessible.
4. Following All Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
5. Hang Hardware by sliding Canopy onto Crossbar Studs. Secure with reserved Brass Balls.
6. Hang Stained Glass Shade by connecting loose ends of Arms to Shade Hooks.
6. Install 3-E26 60Watt Bulbs(not included) into Sockets.
7. Power on and ENJOY!!!

