

# INSTALLATION INSTRUCTIONS

FOR ITEM 171580 9"SQ SENACA HILL TOP DECK LIGHT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. ROOF ASSEMBLY
2. FRAME

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.***

***Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Knobs to separate Roof from Frame.
3. Unscrew Brass Balls from center of Frame to separate Universal Crossbar with Studs. Reserve all for later use.
4. Affix Universal Crossbar to Junction Box ensuring that Electrical Supply Wires remain accessible.
5. Following All Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
6. Set Frame onto Pier allowing Crossbar Studs to pass through center. Secure with Brass Balls.
7. Install E26 60Watt Bulb(not included) into Socket.
8. Set Roof onto frame. Secure Roof with Knobs.
9. Power on and ENJOY!!!

